

IMPORTANT NOTES: Read First

(A) Use liquid thread lock (such as Loctite®) with all threaded hardware. **Important:** Liquid thread lock (prior to curing) helps to eliminate the common problem of "thread seizure" in stainless steel hardware by serving as a lubricant during assembly.

(B) Refer to Installation Manual for 09 Collars and 11 Socket Clamps assembly instructions.

FIGURE 1
Steel Slanted Roof Assembly

See Installation Manual Sections
09 Collars and 11 Clamps




Figure 1.1



NOTE: R5 Roof Assembly shown.

Step 1

Refer to Collar Layout and attach collars to posts.

* Distance between top of collar and bottom of post cap must not exceed 6" [152 mm] on any post.

Collar Layout



Step 2

Attach Steel Slanted Roof Frame to collars as shown in Figure 1.1. (See Notes A & B)

Step 3

Fully tighten all fasteners according to the "TIGHTENING TORQUE FOR HARDWARE" section of the Installation Manual.

Specifications

SLANTED STEEL SHADE ROOF:

Shall be fabricated using 1.315" O.D. 12 gauge steel tubing frame with welded 14 gauge punched sheet steel shades. The Slanted Steel Shade Roof shall have a multi-stage baked-on powder coat finish.

SOCKET CLAMPS:

Shall be two-part and precision die-cast from a high strength aluminum alloy. The Socket Clamps have a multi-stage baked-on powder coat finish.

Parts List

R3.5 ASSEMBLY

Part #	DESCRIPTION	QTY
FS-18014-R35	Slanted Steel Shade Roof R3.5	1
HS-1001-R35	Socket Clamp Set R3.5	4

R5 ASSEMBLY

Part #	DESCRIPTION	QTY
FS-18014-R	Slanted Steel Shade Roof R5	1
HS-1001-R5	Socket Clamp Set R5	4

Maintenance

Periodically tighten all screws, bolts and nuts. A periodic inspection of all parts is necessary. If a part is broken or worn, replace immediately. For general maintenance please refer to our Playground Maintenance Manual.



Manufactured by Krauss Craft, Inc.
www.playcraftsystems.com

For Customer Service Call
800.333.8519 (U.S.A.) or
541.955.9199 (International)

Rev B
5/12/2010