


IMPORTANT NOTES: Read First

(A) Use liquid thread lock (such as Loctite®) with all threaded hardware. **Important:** Liquid thread lock (prior to curing) helps to eliminate the common problem of "thread seizure" in stainless steel hardware by serving as a lubricant during assembly.

FIGURE 1
Small Oracle Panel



NOTE: Small Oracle Panel to steel panel shown. Other configurations will vary slightly, but does not affect assembly.

Step 1 (Factory Assembled)

Attach Arrow and Hubs to Panel as shown in Figure 1.1. (See Note A)




Figure 1.1




FIGURE 2

Step 2a

For Steel Event Panel Only

Attach Small Oracle Panel to Steel Event Panel as shown in Figure 2. (See Note A)




FIGURE 3

Step 2b

For HDPE Event Panel Only

Attach Small Oracle Panel to HDPE Event Panel as shown in Figure 3. (See Note A)

Step 3

Fully tighten all fasteners according to the "TIGHTENING TORQUE FOR HARDWARE" section of the Installation Manual.

Parts List

STEEL MOUNT		
Part #	DESCRIPTION	QTY
9103032-TR	Bolt Button Head 3/8" x 3/4"	6
9333002	Washer Flat 3/8" x 1" O.D. x .100" thick	6
9345002	Washer Flat SAE 1/2"	6
9443022-TR	Nut Barrel 3/8" x 5/8" BH	6

HDPE MOUNT		
Part #	DESCRIPTION	QTY
9103072-TR	Bolt Button Head 3/8" x 1-1/2"	6
9333002	Washer Flat 3/8" x 1" O.D. x .100" thick	6
9345002	Washer Flat SAE 1/2"	6
9443022-TR	Nut Barrel 3/8" x 5/8" BH	6

Assembled Parts List

Part #	DESCRIPTION	QTY
EE-0101-IH	Seek Panel - Inner Hub	1
EE-0101-OH	Seek Panel - Outer Hub	1
EE-0686	Small Oracle Panel	1
EE-0686-A	Small Oracle Panel Arrow	1
9103072-TR	Bolt Button Head 3/8" x 1-1/2"	1
9333002	Washer Flat 3/8" x 1" O.D. x .100" thick	1
9345002	Washer Flat SAE 1/2"	1
9443022-TR	Nut Barrel 3/8" x 5/8" BH	1

Specifications

SMALL ORACLE PANEL, ARROW, INNER & OUTER HUBS:

Shall be made from high density 3/4" sheet plastic specially formulated for optimum UV stability and color retention.

HARDWARE:

Shall be stainless steel, zinc/nickel plated or galvanized as required to resist rust and corrosion.

Maintenance

Periodically tighten all screws, bolts and nuts. A periodic inspection of all parts is necessary. If a part is broken or worn, replace immediately. For general maintenance please refer to our Playground Maintenance Manual.

