


IMPORTANT NOTES: Read First

(A) Use liquid thread lock (such as Loctite®) with all threaded hardware. **Important:** Liquid thread lock (prior to curing) helps to eliminate the common problem of "thread seizure" in stainless steel hardware by serving as a lubricant during assembly.

(B) An appropriate energy absorbing safety surface is required under and around all playground equipment. Loose fill protective surfacing is shown only as an example for the purpose of this assembly instruction. Other surfacing material may vary in thickness and/or compression depths. See free publication - The Handbook for Public Playground Safety, Publication #325 at www.cpsc.gov for the surfacing appropriate for the fall height of the equipment or consult your surfacing supply representative.

FIGURE 1
Launch Pad Seat and Step



NOTE: Launch Pad Seat shown.
Other configuration will vary, but
does not affect assembly.

Step 1

For both Launch Pad Seat and Step refer to Sight Plan for alignment, orientation, and elevation.

Elevation View





FIGURE 3

Step 2

Attach Launch Pads and or Seat to Post as shown in Figure 3.
(See Note A)

Step 3

Fully tighten all fasteners according to the "TIGHTENING TORQUE FOR HARDWARE" section of the Installation Manual.

Step 4

Place required protective surfacing under and around Launch Pad Assembly. (See Note B)

LAUNCH PAD SEAT AND STEP INSTALLATION INSTRUCTIONS

RV-21260/21263
Page 3 of 3

Parts List

LAUNCH PAD SEAT		
Part #	DESCRIPTION	QTY
9103072-TR	Bolt Button Head 3/8" x 1-1/2"	24
9333002	Washer Flat 3/8" x 1" O.D. x .100" thick	24
DH-0001	Launch Pad Step Half	2
DH-0004	Launch Pad Seat	1

LAUNCH PAD STEP		
Part #	DESCRIPTION	QTY
DH-0001	Launch Pad Step Half	2
9103072-TR	Bolt Button Head 3/8" x 1-1/2"	12
9333002	Washer Flat 3/8" x 1" O.D. x .100" thick	12

Specifications

LAUNCH PAD SEAT & STEP:

Shall be constructed of UV-stabilized, rotationally molded, linear, low density polyethylene with an average wall thickness of .250".

HARDWARE:

Shall be stainless steel, zinc/nickel plated or galvanized as required to resist rust and corrosion.

Maintenance

Periodically tighten all screws, bolts and nuts. A periodic inspection of all parts is necessary. If a part is broken or worn, replace immediately. For general maintenance please refer to our Playground Maintenance Manual.



www.playcraftsystems.com
For Customer Service Call
800.333.8519 (U.S.A.) or 541.955.9199 (International)

Rev A
12/20/2023