


IMPORTANT NOTES: Read First

(A) Use liquid thread lock (such as Loctite®) with all threaded hardware. **Important:** Liquid thread lock (prior to curing) helps to eliminate the common problem of "thread seizure" in stainless steel hardware by serving as a lubricant during assembly.

(B) Do not pour concrete until the equipment is completely assembled, leveled and plumbed. Concrete must be allowed to cure completely before using the equipment (at least 72 hours).

(C) An appropriate energy absorbing safety surface is required under and around all playground equipment. Loose fill protective surfacing is shown only as an example for the purpose of this assembly instruction. Other surfacing material may vary in thickness and/or compression depths. See free publication - The Handbook for Public Playground Safety, Publication #325 at www.cpsc.gov for the surfacing appropriate for the fall height of the equipment or consult your surfacing supply representative.

FIGURE 1
Triple Hoop




Step 1

Refer to Footing Layout and mark footing hole location(s). Dig (1) Ø 18" footing hole. Refer to Footing Detail for depth and details.

IMPORTANT: For areas with soft soil conditions, larger footings may be required.

* Footing depth must be adjusted to compensate for the depth/thickness requirements of selected safety surfacing. See Section 06.1 of the Installation Manual.

Footing Detail



Step 2 (Factory Assembled)

Attach Vent Plug to Triple Hoop as shown in Figure 2.




FIGURE 2

Step 3 (Factory Assembled)

Attach Cap to Triple Hoop as shown in Figure 3.




FIGURE 3




FIGURE 4

Step 4

Attach Hex Bolt to Post as shown in Figure 4.
(See Note A)

Step 5

Attach Triple Hoop to post as shown in Figure 5.

NOTE: Ensure that the post is fully inserted 12" into the Triple Hoop.

Step 6

Fully tighten all fasteners according to the "TIGHTENING TORQUE FOR HARDWARE" section of the Installation Manual.

Step 7

Plumb and level entire component. Pour concrete into footing hole. Allow at least 72 hours to cure before using this equipment. (See Note B)

Step 8

Place required protective surfacing under and around Triple Hoop. (See Note C)




FIGURE 5

TRIPLE HOOP INSTALLATION INSTRUCTIONS

PC-1809
Page 4 of 4

Parts List

Part #	DESCRIPTION	QTY.
JG-1009-NC	9' Post R35 No Cap	1
9123231	Bolt Hex 3/8" x 5-1/2"	1
9271082-TR	1/4" x 1 3/4" Tek Screw	3
9321052-THK	Washer Fender 1/4" x 1" OD x .125" thk	3
9483602	Nut Hex 3/8"	1

Assembled Parts List

Part #	DESCRIPTION	QTY.
DE-0042	Triple Hoop	1
EE-0248	Triple Hoop Cap	1
EE-4867	Geo-Wave Vent Plug	2
9251032	Screw SQ #10x3/4 DR PH SMS SS	9

Specifications

9' POST R35:

Shall be fabricated using 3.5" O.D. 11 gauge steel tubing.

CAP & PLUGS:

Shall be made from high density 3/4" sheet plastic specially formulated for optimum UV stability and color retention.

TRIPLE HOOP:

Shall be constructed of UV-stabilized, rotationally molded, linear, low density polyethylene with an average wall thickness of .250".

HARDWARE:

Shall be stainless steel, zinc/nickel plated or galvanized as required to resist rust and corrosion.

Maintenance

Periodically tighten all screws, bolts and nuts. A periodic inspection of all parts is necessary. If a part is broken or worn, replace immediately. For general maintenance please refer to our Playground Maintenance Manual.



Manufactured by Krauss Craft, Inc.
www.playcraftsystems.com

For Customer Service Call
800.333.8519 (U.S.A.) or
541.955.9199 (International)

Rev A
11/9/2012