



## Parts List

QTY.	DESCRIPTION	PART #
1	Boardwalk Beam Wave	FS-1965-W
3	Boardwalk Leg	FS-1965-LEG
6	3/8x3/4" Button Hd Bolt	9103032-TR
6	5/8" Barrel Nut	9443021-TR
6	1/2" SAE Washer	9345002
12	3/8x1" O.D. Washer	9333002

## Specifications

### BOARDWALK:

Top Rail shall be fabricated from 2" Dia. 11 GA steel tubing with welded-on 1/4 thick steel brackets, and finished with a baked-on powdercoat. Boardwalk Treads are formed 12 GA punched steel and finished with a vinyl-coating.

### LEGS:

Legs shall be fabricated from 1 1/4" Galv. pipe with 3/8" steel mounting tabs. Finished with a baked-on powdercoat.

### HARDWARE:

Shall be stainless steel as required to resist rust and corrosion.

## Maintenance

Periodically tighten all screws, bolts and nuts. A periodic inspection of all parts is necessary. If a part is broken or worn, replace immediately.

## Installation

### NOTES:

(A) According to safety guidelines, the top surface of the treads shall be no greater than the following heights above the protective surfacing:

Ages 2-5: 12 inches maximum

Ages 5-12: 16 inches maximum

(B) Use liquid thread lock (such as Loctite) with all threaded hardware. **Important:** Liquid thread lock (prior to curing) helps to eliminate the common problem of "thread seizure" in stainless steel hardware by serving as a lubricant during assembly.

### Step 1.

Dig 3 footing holes Approx. 12" Dia. Refer to Figure 2 for layout. See Note A to determine footing depth with consideration to ages and ground cover thickness.

### Step 2.

Attach Legs to the Beam with hardware shown in Figure 3.

### Step 3.

Place Boardwalk assembly in position. Check for level and finished height considering ground cover.

### Step 4.

Pour concrete footings and allow at least 72 hours to cure.

### Step 5.

Place protective ground cover over footings and surrounding area.