

### IMPORTANT NOTES: Read First

(A) Use liquid thread lock (such as Loctite®) with all threaded hardware. **Important:** Liquid thread lock (prior to curing) helps to eliminate the common problem of "thread seizure" in stainless steel hardware by serving as a lubricant during assembly.


(B) This Assembly requires additional Assembly Pages. See also Assembly Page R5-09 Collars and R5-11 Socket Clamps.

(C) Collar Locations : Collars measure 33-5/8" from top of upper collar to top of middle collar and 12" from top of middle collar to top of lower collar.

**Under Deck Installation:** Make sure distance between the bottom of the deck and the top of the panel(s) is less than 3-1/2" or greater than 9" to avoid head and neck entrapment.


(D) Use appropriate compliant protective surfacing and adjust footing depths accordingly. See free publication - The Handbook for Public Playground Safety, Publication #325 at [www.CPSC.gov](http://www.CPSC.gov) for the surfacing appropriate for the fall height of the equipment or consult you surfacing supply representative.

### Assembly View



See Assembly Page R5-09 Collars and R5-11 Socket Clamps

See Figure 1  
Mounting Lug Connection




\*Dimensions given are from Top of Collar to Top Collar

See Note C

33 5/8"\*  
[854.08 mm]  
See Note C

12"\*  
[304.80 mm]



### Elevation

Front View

### Post Spacing

Top View




Manufactured by Krauss Craft, Inc.  
[www.playcraftsystems.com](http://www.playcraftsystems.com)

For Customer Service Call  
800.333.8519 (U.S.A.) or  
541.955.9199 (International)

Rev C

### Figure 1

Mounting Lug  
Connection,  
6 Pl.



### Parts List

<b>PART #</b>	<b>DESCRIPTION</b>	<b>QTY.</b>
007007	Mounting Lug R5	6
126010	Panel Door Roto Tall	1
See Pg. R5-11	Socket Clamp Assy.	6
9103082-TR	Bolt Button Head 3/8" x 1-3/4"	6
9333002	Washer Flat 3/8" x 1" x .100 thick	6

### Installation

#### Step 1.

Locate and mark the position of the Collars on the Support Posts. See Note C. Refer to Assembly Page R5-09 Collars for additional details and hardware.

#### Step 2.

Loosely attach the top of the Panel to the Collars using Socket Clamps and Mounting Lugs. Refer to Figure 1 for hardware type and orientation. See also Assembly Page R5-11 Socket Clamps.

#### Step 3.

Repeat Step 3 to attach the rest of the Panel to Collars.

#### Step 4.

Check distance between top of Panel and bottom of Deck to make sure it doesn't create an Entrapment. See Note C for details.

#### Step 5.

Apply liquid thread lock and fully tighten all fasteners according to the "TIGHTENING TORQUE FOR HARDWARE" Section of the Installer's Manual. See Note A.

#### Step 6.

Place appropriate compliant protective surfacing under and around Door Panel Tall Roto. See Note D.

### Specifications

#### PANEL DOOR TALL R5 ROTO:

Shall be constructed of UV-stabilized, rotationally molded, Linear Low Density Polyethylene with an average single wall thickness of 1/4". The Panel (ROTO) shall be 38" x 55-1/2" x 3" deep.

#### SOCKET CLAMPS:

Shall be two-part and precision die-cast from a high strength aluminum alloy. The Socket Clamps have a multi-stage baked-on powder coat finish.

#### MOUNTING LUGS:

Shall be precision die-cast from a high-strength aluminum alloy. The Mounting Lugs have a multi-stage baked-on powder coating.

#### HARDWARE:

Shall be stainless steel, zinc/nickel plated or galvanized as required to resist rust and corrosion.

### Maintenance

Periodically tighten all screws, bolts and nuts. A periodic inspection of all parts is necessary. If a part is broken or worn, replace immediately. For general maintenance please refer to our Playground Maintenance Manual.

