

IMPORTANT NOTES: Read First


(A) Use liquid thread lock (such as Loctite®) with all threaded hardware. **Important:** Liquid thread lock (prior to curing) helps to eliminate the common problem of "thread seizure" in stainless steel hardware by serving as a lubricant during assembly.

(B) Do not pour concrete until the equipment is completely assembled, leveled and plumbed. Concrete must be allowed to cure completely before using the equipment (at least 72 hours).

(C) Refer to Installation Manual for R5-1314 Access Wall or 1677 Tree House Panels installation instructions.

(D) An appropriate energy absorbing safety surface is required under and around all playground equipment. Loose fill protective surfacing is shown only as an example for the purpose of this assembly instruction. Other surfacing material may vary in thickness and/or compression depths. See free publication - The Handbook for Public Playground Safety, Publication #325 at www.cpsc.gov for the surfacing appropriate for the fall height of the equipment or consult your surfacing supply representative.

FIGURE 1
Stump Climber




Step 1


Refer to Footing Layout and mark footing hole locations. Dig (5) Ø 12" footing holes. Refer to Footing Detail for depth and details.

IMPORTANT: For areas with soft soil conditions, larger footings may be required.

* Footing depth must be adjusted to compensate for the depth/thickness requirements of selected safety surfacing. See Section 06.1 of the Installation Manual.



Top View - Footing Layout



Step 2 (Factory Assembled)

Attach Stump Caps to Stump Climber as shown in Figure 2. (See Note A)

Step 3

Attach Access Wall to deck and collars. (See Note C)




Figure 1.1




FIGURE 2

Step 4

Attach Legs to Stump Climber as shown in Figure 1.1. (See Note A)

Step 5

Fully tighten all fasteners according to the "TIGHTENING TORQUE FOR HARDWARE" section of the Installation Manual.

Step 6

Place Legs into footing holes and firmly lock Stump Climber against post as shown in Figure 3. (See Note B)

Step 7

Plumb and level entire component. Pour concrete into footing holes. Allow at least 72 hours to cure before using this equipment. (See Note B)

Step 8

Place required protective surfacing under and around Stump Climber. (See Note D)




FIGURE 3

STUMP CLIMBER R5

INSTALLATION INSTRUCTIONS

R5-1292
Page 4 of 4

Parts List

Part #	DESCRIPTION	QTY.
FS-1849-LEG	Tree Root Leg	5
9103132-TR	Bolt Button Head 3/8" x 3"	5
9333002	Washer Flat 3/8" x 1" O.D. x .100" thick	10
9413002	Nut Lock 3/8"	5

Assembled Parts List

Part #	DESCRIPTION	QTY.
DF-0001	Stump Climber	1
EE-0203-1	Stump Cap 1	1
EE-0203-2	Stump Cap 2	1
EE-0203-3	Stump Cap 3	1
9103052-TR	Bolt Button Head 3/8" x 1"	9
9333002	Washer Flat 3/8" x 1" O.D. x .100" thick	9

Specifications

STUMP CLIMBER:

Shall be constructed of UV-stabilized, rotationally molded, linear, low density polyethylene with an average wall thickness of .250".

STUMP CAP:

Shall be made from high density 3/4" sheet plastic specially formulated for optimum UV stability and color retention.

TREE ROOT LEG:

Shall be fabricated using 1.029" O.D. 14 gauge steel tubing with welded 3/16" thick steel mounting plate. The Tree Root Leg shall have a multi-stage baked-on powder coat finish.

HARDWARE:

Shall be stainless steel, zinc/nickel plated or galvanized as required to resist rust and corrosion.

Maintenance

Periodically tighten all screws, bolts and nuts. A periodic inspection of all parts is necessary. If a part is broken or worn, replace immediately. For general maintenance please refer to our Playground Maintenance Manual.



www.playcraftsystems.com
For Customer Service Call
800.333.8519 (U.S.A.) or 541.955.9199 (International)

Rev A
2/15/2022