

Assembly View




Figure 1




Figure 2






Figure 3



Plan View



Parts List

<u>QTY.</u>	<u>DESCRIPTION</u>	<u>PART #</u>
1	ROTO Free Form Climb Wall	4705
1	Free Form Climber Legs	FS-1238
9	3/8" x 1" Button Hd. Bolts	9103052-TR
2	3/8" x 1-1/4" Button Hd. Bolts	9103062-TR
13	3/8" x 1" O.D. Washers	9333002
9	1/2" SAE Washers	9345002
2	3/8" Lock Nuts	9413002
9	3/8" x 5/8" Barrel Nuts	9443022-TR

Installation

Notes:

(A) Half Walls are required for this assembly. Refer to Assembly Page R5-1309.

(B) Use liquid thread lock (such as Loctite) with all threaded hardware not including self-locking nuts

Step 1.

Attach Climber Legs to Climb Wall as shown in Figure 1.

Step 2.

Dig (2) 12" Dia. footing holes approx. 30" deep (See Figure 2). See Plan View for locations.

Step 3.

Place assembled Free Form Climber into footing holes and attach to deck face as shown in Figure 3.

Step 4.

Pour concrete footings and allow concrete to cure for 72 hours before continuing.

Step 5.

Fully tighten all fasteners.

Specifications

FREE FORM CLIMBER:

Shall be made from hot compounded LLDPE plastic.

CLIMBER LEGS:

Shall be made of 2.375" O.D., 10 gage steel tubing with welded deck mount and brackets. Deck mount will be made of 1.315" O.D., 12 gage steel tube with welded .25" thick HR steel bracket.

HARDWARE:

Shall be zinc/nickel plated, galvanized or stainless steel as required to resist rust and corrosion.

Maintenance

Periodically tighten all screws, bolts and nuts. A periodic inspection of all parts is necessary. If a part is broken or worn, replace immediately.

