

IMPORTANT NOTES: Read First


(A) Use liquid thread lock (such as Loctite®) with all threaded hardware. **Important:** Liquid thread lock (prior to curing) helps to eliminate the common problem of "thread seizure" in stainless steel hardware by serving as a lubricant during assembly.

(B) Do not pour concrete until the equipment is completely assembled, leveled and plumbed. Concrete must be allowed to cure completely before using the equipment (at least 72 hours).

(C) Refer to Installation Manual for 09 Collars, 11 Socket Clamps, and 1309 Half Wall installation instructions.

(D) An appropriate energy absorbing safety surface is required under and around all playground equipment. Loose fill protective surfacing is shown only as an example for the purpose of this assembly instruction. Other surfacing material may vary in thickness and/or compression depths. See free publication - The Handbook for Public Playground Safety, Publication #325 at www.cpsc.gov for the surfacing appropriate for the fall height of the equipment or consult your surfacing supply representative.

**FIGURE 1
Narrow Net Climber**




Step 1

Refer to Footing Layout and mark footing hole location. Dig (1) 12" x 24" footing hole. Refer to Footing Detail for depth and details.


IMPORTANT: For areas with soft soil conditions, larger footings may be required. Additionally, half foot deck heights will require a 6" deeper footing hole.

* Footing depth must be adjusted to compensate for the depth/thickness requirements of selected safety surfacing. See Section 06.1 of the Installation Manual.

Elevation View - Footing Detail



Top View - Footing Layout



Step 2

Attach Chains to Narrow Net Climber as shown in Figure 1.1. (See Note A)




Figure 1.1




FIGURE 2

Step 3

Attach Bracket to Deck as shown in Figure 2. (See Note A)

Step 4

Attach Narrow Net Climber to Bracket as shown in Figure 1.2. (See Note A)

Step 5

Fully tighten all fasteners according to the "TIGHTENING TORQUE FOR HARDWARE" section of the Installation Manual.

Step 6

Plumb and level entire component. Place chains tight into footing hole. Pour concrete into footing hole. Allow at least 72 hours to cure before using this equipment. (See Note B)

Step 7

Place required protective surfacing under and around Narrow Net Climber. (See Note D)




Figure 1.2

NARROW NET CLIMBER INSTALLATION INSTRUCTIONS

12462
Page 4 of 4

Parts List

Part #	DESCRIPTION	QTY
FS-12462-BRKT	Narrow Net Climber Bracket	1
HE-0008-16	16-Link Galvanized Chain	2
HE-0145	Narrow Net Climber-Net	1
451161-SS	Swing Shackle - Stainless Steel	2
9103062-TR	Bolt Button Head 3/8" x 1-1/4"	4
9103072-TR	Bolt Button Head 3/8" x 1-1/2"	2
9103200-TR	Bolt Button Head 3/8" x 1-7/16"	2
9333002	Washer Flat 3/8" x 1" O.D. x .100" thick	12
9333042	Washer Flat 3/8" x 7/8" O.D.	4
9413002	Nut Lock 3/8"	6
9423002	Nut Lock Thin 3/8"	2

Specifications

NARROW NET CLIMBER BRACKET:

Fabricated using 1/4" thick steel plate with welded 3/16" thick steel anchors and will have a multi-stage baked-on powder coat finish.

16-LINK GALVANIZED CHAIN:

Fabricated from 5/0 galvanized steel chain with silver shield finish.

NARROW NET CLIMBER-NET:

Fabricated from 16mm steel-reinforced rope with high-strength polymer intersections and machined aluminum end ferrules.

HARDWARE:

Fabricated from stainless steel, zinc/nickel plated or galvanized to resist rust and corrosion.

Maintenance

Periodically tighten all screws, bolts and nuts. A periodic inspection of all parts is necessary. If a part is broken or worn, replace immediately. For general maintenance please refer to our Playground Maintenance Manual.



www.playcraftsystems.com
For Customer Service Call
800.333.8519 (U.S.A.) or 541.955.9199 (International)

Rev A
8/4/2021