



WELCOME SIGN

PC 1303

Page 2 of 2

Parts List

<u>QTY.</u>	<u>DESCRIPTION</u>	<u>PART #</u>
1	Sign	varies
1	Sign Post (OR)	FS- PC1301
1	Sign Frame	FS-PC1302

Installation

Step 1.

Dig footing hole(s) Approx. 18" deep by 12" Dia.

Step 2.

Position Sign Post in hole. Check for plum.

Step 3.

Pour concrete footings.

Specifications

Sign Frame:

Shall be 2" Sch. 40 pipe with laser-cut steel brackets. Weldment to be powder coated.

Sign Post:

Shall be a 2x2 Sq. tube. Weldment to be powder coated.

Sign:

Shall be 3/4" plastic laminate.

Maintenance

Periodically tighten all screws, bolts and nuts.
A periodic inspection of all parts is necessary.
If a part is broken or worn, replace immediately.



Manufactured by
Krauss Craft, Inc.

Phone: 800.333.8519

Rev. B