

IMPORTANT NOTES: Read First

(A) Use liquid thread lock (such as Loctite®) with all threaded hardware. **Important:** Liquid thread lock (prior to curing) helps to eliminate the common problem of "thread seizure" in stainless steel hardware by serving as a lubricant during assembly.

(B) Do not pour concrete until the equipment is completely assembled, leveled and plumbed. Concrete must be allowed to cure completely before using the equipment (at least 72 hours).


(C) All gaps created between Craze Components must be less than 3-1/2" [89mm] or greater than 9" [229mm].

(D) Refer to the Site Plan included with the Installation Guidelines for additional Footing Layout dimensions and Maze orientation. Actual hole locations may vary according to system design.

(E) Refer to Installation Manual for 21263 Launch Pad Step installation instructions.

(F) An appropriate energy absorbing safety surface is required under and around all playground equipment. Loose fill protective surfacing is shown only as an example for the purpose of this assembly instruction. Other surfacing material may vary in thickness and/or compression depths. See free publication - The Handbook for Public Playground Safety, Publication #325 at www.cpsc.gov for the surfacing appropriate for the fall height of the equipment or consult your surfacing supply representative.

**FIGURE 1
Craze Maze Climber**



NOTE: RH5 Craze Maze Climber shown. Other configurations will vary slightly, but does not affect assembly.

Step 1

Refer to Site Plan for alignment and orientation. Slide Launch Pads, Craze Components and Handles onto posts.

NOTE: Remove required Hole Plugs for Revolution assembly before sliding parts onto posts.

* Height shown from finish grade to top of component.

Elevation View





Figure 1.1a




Figure 1.1b

Step 2

Ensure Craze Components are plum, level and correctly spaced. Refer to Figure 1.1a for R5 Post Assembly or Figure 1.1b for RV Post Assembly and secure Craze Components to posts. (See Notes A, B, C & D)

Step 3

Plumb and level entire component. Pour concrete into footing holes. Allow at least 72 hours to cure before using this equipment. (See Note B)

Step 4

Fully tighten all fasteners according to the "TIGHTENING TORQUE FOR HARDWARE" section of the Installation Manual.

Step 5

Place required protective surfacing under and around Craze Maze Climber. (See Note F)

Parts List

S-1295-R5		
Part #	DESCRIPTION	QTY.
DE-0058	Craze Handle	1
9271082-TR	1/4" x 1 3/4" Tek Screw	4
9321052-THK	Washer Fender 1/4" x 1" OD x .125" thk	4

S-1295-RV		
Part #	DESCRIPTION	QTY.
DE-0058	Craze Handle	1
9103052-TR	Bolt Button Head 3/8" x 1"	4
9333002	Washer Flat 3/8" x 1" O.D. x .100" thick	4

S-1296-R5		
Part #	DESCRIPTION	QTY.
DE-0057	Craze Component	1
9271082-TR	1/4" x 1 3/4" Tek Screw	8
9321052-THK	Washer Fender 1/4" x 1" OD x .125" thk	8

S-1296-RV		
Part #	DESCRIPTION	QTY.
DE-0057	Craze Component	1
9103052-TR	Bolt Button Head 3/8" x 1"	8
9333002	Washer Flat 3/8" x 1" O.D. x .100" thick	8

Specifications

CRAZE COMPONENT & HANDLE:

Shall be constructed of UV-stabilized, rotationally molded, linear, low density polyethylene with an average wall thickness of .250".

HARDWARE:

Shall be stainless steel, zinc/nickel plated or galvanized as required to resist rust and corrosion.

Maintenance

Periodically tighten all screws, bolts and nuts. A periodic inspection of all parts is necessary. If a part is broken or worn, replace immediately. For general maintenance please refer to our Playground Maintenance Manual.

