


## **IMPORTANT NOTES: Read First**

(A) Use liquid thread lock (such as Loctite®) with all threaded hardware. **Important:** Liquid thread lock (prior to curing) helps to eliminate the common problem of "thread seizure" in stainless steel hardware by serving as a lubricant during assembly.

(B) All gaps created between stacked panels must be less than 3-1/2" [89mm] or greater than 9" [229mm].

(C) An appropriate energy absorbing safety surface is required under and around all playground equipment. Loose fill protective surfacing is shown only as an example for the purpose of this assembly instruction. Other surfacing material may vary in thickness and/or compression depths. See free publication - The Handbook for Public Playground Safety, Publication #325 at [www.cpsc.gov](http://www.cpsc.gov) for the surfacing appropriate for the fall height of the equipment or consult your surfacing supply representative.



**FIGURE 1**  
Sectional Lunar Climber

**NOTE:** Single Sectional Lunar Climber shown. Other configurations will vary slightly, but does not affect assembly.


### Step 1

Refer to Elevation View, locate mounting holes and remove required Hole Plugs for assembly.

\* Height shown from finish grade to mounting hole.

**NOTE:** Stacked Lunar Climber shown for purpose of locating optional panels.

Elevation View



### Step 2 (Factory Assembled)

Attach Center and Outside Trim to Sectional Lunar Climber Panel as shown in Figure 2. (See Note A)






FIGURE 2

## Step 3

Refer to Elevation View and attach Tab Brackets to posts as shown in Figure 1.1.  
(See Notes A & B)



**Figure 1.1**



**Figure 1.2**

## Step 4

Attach Tab Brackets to Sectional Lunar Climber Panel as shown in Figure 1.2. (See Note A)

## Step 5

Fully tighten all fasteners according to the "TIGHTENING TORQUE FOR HARDWARE" section of the Installation Manual.

## Step 6

Place required protective surfacing under and around Sectional Lunar Climber. (See Note C)

# SECTIONAL LUNAR CLIMBER RV INSTALLATION INSTRUCTIONS

**RV-12591**  
Page 4 of 4

## Parts List

Part #	DESCRIPTION	QTY.
FS-1510-RV-OT	Post Offset Tab Bracket	4
4-9339042	Washer Flat 3/8" x 7/8" O.D. x .100" Thick	8
9103052-TR	Bolt Button Head 3/8" x 1"	12
9333002	Washer Flat 3/8" x 1" O.D. x .100" thick	4
9345002	Washer Flat SAE 1/2"	4
9443022-TR	Nut Barrel 3/8" x 5/8" BH	4

## Assembled Parts List

Part #	DESCRIPTION	QTY.
EH-0001	Sectional Lunar Climber Panel	1
EH-0001-CT	Sectional Lunar Climber Center Trim	2
EH-0001-OT	Sectional Lunar Climber Outside Trim	2
9103052-TR	Bolt Button Head 3/8" x 1"	6
9333042	Washer Flat 3/8" x 7/8" O.D.	6
9345002	Washer Flat SAE 1/2"	6
9443092-TR	Nut Barrel 3/8" x 2" BH	6

## Specifications

### POST OFFSET TAB BRACKET:

Shall be fabricated using 1/4" steel mounting bracket with welded 3/8" thick steel tab. Post Offset Tab Bracket shall have a multi-stage baked-on powder coat finish.

### SECTIONAL LUNAR CLIMBER PANEL, CENTER & OUTSIDE TRIM:

Shall be made from high density 3/4" sheet plastic specially formulated for optimum UV stability and color retention.

### HARDWARE:

Shall be stainless steel, zinc/nickel plated or galvanized as required to resist rust and corrosion.

## Maintenance

Periodically tighten all screws, bolts and nuts. A periodic inspection of all parts is necessary. If a part is broken or worn, replace immediately. For general maintenance please refer to our Playground Maintenance Manual.



Manufactured by Krauss Craft, Inc.  
[www.playcraftsystems.com](http://www.playcraftsystems.com)

For Customer Service Call  
800.333.8519 (U.S.A.) or  
541.955.9199 (International)

**Rev A**  
1/13/2012