


IMPORTANT NOTES: Read First

(A) Use liquid thread lock (such as Loctite®) with all threaded hardware. **Important:** Liquid thread lock (prior to curing) helps to eliminate the common problem of "thread seizure" in stainless steel hardware by serving as a lubricant during assembly.

(B) The maximum height of rungs (at grasping point) from the top of the protective surfacing varies by age group: Ages 2-5: 60" [1524mm] above protective surfacing. Ages 5-12: 84" [2130mm] above protective surfacing.

(C) An appropriate energy absorbing safety surface is required under and around all playground equipment. See free publication - The Handbook for Public Playground Safety, Publication #325 at www.cpsc.gov for the surfacing appropriate for the fall height of the equipment or consult your surfacing supply representative.

FIGURE 1
Ring Pull-Up RV



Step 1

Refer to Elevation View, locate mounting holes and remove required Hole Plugs for assembly.

*Height Shown from finish grade to mounting hole.





Figure 1.1

Step 2

Attach Tri-Ring to Traverse Beam as shown in Figure 1.1. (See Note A)

Step 3

Attach Traverse Beam to Post as shown in Figure 1.2.
(See Note A)

Step 4

Fully tighten all fasteners according to the
"TIGHTENING TORQUE FOR HARDWARE" section of
the Installation Manual.

Step 5

Place required protective surfacing under
and around Ring Pull-Up . (See Note C)




Figure 1.2

Parts List

Part #	DESCRIPTION	QTY
FS-1936-RV	Ring Pull-Up Beam RV	1
4-9339042	Washer Flat 3/8" x 7/8" O.D. x .100" Thick	4
411000	Tri-Ring	2
451161-SS	Swing Shackle - Stainless Steel	2
471002	Swing Hanger w/ Nut & Bolt	2
9103052-TR	Bolt Button Head 3/8" x 1"	4

Specifications

RING PULL-UP BEAM:

Shall be fabricated using 2.375" O.D. 10 gauge steel tubing, 1/4" thick stainless steel mounting brackets, and 3/16" steel hangers. The Ring Pull-Up Beam shall have a multi-stage baked-on powder coat finish.

HARDWARE:

Shall be stainless steel, zinc/nickel plated or galvanized as required to resist rust and corrosion.

Maintenance

Periodically tighten all screws, bolts and nuts. A periodic inspection of all parts is necessary. If a part is broken or worn, replace immediately. For general maintenance please refer to our Playground Maintenance Manual.