

IMPORTANT NOTES: Read First



(A) Do not pour concrete until the Equipment is completely assembled, leveled and plumbed. Concrete must be allowed to cure completely before using the equipment (at least 72 hours).

(B) **Sign Option:** If a Sign is included See Assembly Page PC 2509-STA Station Sign.

(C) Use appropriate compliant protective surfacing and adjust footing depths accordingly. See free publication - The Handbook for Public Playground Safety, Publication #325 at www.CPSC.gov for the surfacing appropriate for the fall height of the equipment or consult your surfacing supply representative.


(D) Optional Station Sign is to be located outside use zone per manufacturer's recommendation. The Parallel Bars have a recommended use zone that should extend a minimum of 6 feet in all directions from the perimeter of the equipment. The use zones of two stationary pieces of playground equipment that are positioned adjacent to one another may overlap if the adjacent designated play surfaces of each structure are no more than 30 inches above the protective surface. See free publication - The Handbook for Public Playground Safety, Publication #325 at www.CPSC.gov for more information on overlapping use zones.

Assembly View



Elevation

Side View



*See Note D

Footing Layout

Bottom View




Manufactured by Krauss Craft, Inc.
www.playcraftsystems.com

For Customer Service Call
800.333.8519 (U.S.A.) or
541.955.9199 (International)

Rev C

Figure 1

**Footing
Detail**



PARALLEL BARS

PC 2550

Page 3 of 3

Parts List

<u>PART #</u>	<u>DESCRIPTION</u>
---------------	--------------------

FS-PC2550	Parallel Bar
-----------	--------------

<u>QTY.</u>

1 Pair

Installation

Step 1.

Refer to Footing Layout and mark footing hole locations. Dig (4) 12"Ø footing holes. Refer to Figure 1 for depth and details. **Important:** For areas with soft soil conditions, larger footings may be required.

Step 2.

Set the Parallel Bars into footing holes. Plumb and level Parallel Bars. Block and brace prior to pouring concrete into footing holes. Refer to Figure 1 for details. Allow 72 hours to cure before using this equipment. See Note A.

Step 3.

Place appropriate compliant protective surfacing under and around Parallel Bars. See Note C.

Specifications

PARALLEL BARS:

Shall be made of 1.900" O.D., 11 ga. steel tubing with (2) 5/8" round bar as footing anchors. The Parallel Bars have a multi-stage baked-on powder coat finish.

Maintenance

Periodically tighten all screws, bolts and nuts. A periodic inspection of all parts is necessary. If a part is broken or worn, replace immediately. For general maintenance please refer to our Playground Maintenance Manual.



Manufactured by Krauss Craft, Inc.
www.playcraftsystems.com

For Customer Service Call
800.333.8519 (U.S.A.) or
541.955.9199 (International)

Rev C